

HOME | AEROSPACE | ARTICLE

JUNE 1, 2020 | AEROSPACE | MATERIALS | TEST & MEASUREMENT

Does Your Coating Thickness Meet Spec?



Modern handheld devices like this Kett coatings analyzer are now available to allow personnel to perform lab-quality coating thickness measurements using one hand, even on curved and complex surfaces.



From the aerospace OEM assembly line and spray booth to soaring mission critical maneuvers and the maintenance, repair and overhaul (MRO) hangar, it is vital that leading edge aircraft be made to spec and precisely coated for reliable performance, protection, and prolonged life. So, the aerospace industry needs accurate coating thickness measurement whenever plating, anodizing, powder coating or other coatings are required. This is particularly important when the coatings play a critical role in preventing the corrosion or wear of metal substrates.

Properly applied coatings, with thickness measured in mils (.001 inch) or microns (.001 mm) are crucial to avoid coating breaches leading to corrosion of the underlying substrate. Precise application to spec, along with coating measurement, can also help to prevent leaks and other safety issues.

Until recently, however, conducting frequent laboratory-quality coating thickness tests throughout the manufacturing process or in the field has been difficult. Traditionally, this required meticulous sampling and preparation, as well as taking the sample to the lab for evaluation. Although portable coating thickness gauges are not new, most fail to provide the accuracy, speed, or simplicity required for anyone to conduct quick checks as needed on the production line or in the field.

TOP STORIES

INSIDER: DEFENSE
 Jet Propulsion Without Fossil Fuel

INSIDER: AEROSPACE
 NASA Develops Unique Materials for Next Generation Aircraft

INSIDER: TEST & MEASUREMENT
 Hypersonic Glide Vehicle Successfully Tested

INSIDER: AEROSPACE
 Boeing Unmanned Plane Launches for U.S. Space Force - Aerospace & Defense...

INSIDER: DEFENSE
 First Restartable Rocket Motor

ARTICLES: SOFTWARE
 Bringing Turbine Power to Small Aircraft

WEBCASTS

TRENDING STORIES

INSIDER: PROPULSION
 Jet Propulsion Without Fossil Fuel

ARTICLES: PHOTONICS/OPTICS
 Detecting Drones with Doppler-Based Radar

INSIDER: DEFENSE
 Air Force Gunsmith Shop Creates Rifle for Aircrew

INSIDER: AEROSPACE
 First Restartable Rocket Motor

Fortunately, handheld devices are now available that allow personnel to easily and quickly perform lab-quality coating thickness measurements. Some options offer instant coating thickness measurement of almost any non-magnetic coating on both ferrous (magnetic) and non-ferrous (non-magnetic) substrates. This is possible using only one hand, even on curved and complex surfaces. By simplifying the process, aerospace OEMs and MROs can increase the quality of their products and services from start to finish while optimizing cost.

THE BENEFITS OF COATING THICKNESS READINGS

Coating thickness directly affects aircraft and component quality, whether for paint, electroplating, anodizing, or a wide range of other coating applications. For example, checking the paint coating consistency on an aircraft or component not only provides a superior finish, but can also offer essential data about paint consistency when it is wet.

Incorrect paint consistency can affect drying times or eventual flaking of the paint film. Too little paint coating and you are left with cosmetic issues in opacity, and protective issues like corrosion, wear, and exposure.



Some instruments offer instant coating thickness measurement of almost any non-magnetic coating on both ferrous (magnetic) and non-ferrous (non-magnetic) substrates.

When specificity and adhesion matter in anodizing and electroplating, a coating thickness gauge should be able to read the thickness of the coating to the most minute measurement. This can play a major factor in preventing corrosion while optimizing the process by eliminating any excess use of the expensive plating product. Another way a coating thickness gauge can make a significant impact is in testing anti-corrosion coatings in pipe or piping to find weak spots, where the coating is too thin and a breach of the coating could make the substrate susceptible to corrosion.

Knowing about these trouble spots can prevent a problem well before it occurs. This could involve aircraft engine piping and tubing or exhaust pipes. A nondestructive gauge is a perfect way to ensure that the protective coating has not been applied too thinly or become so over time. Excessively thin coatings are more likely to be chipped or breached, which can lead to corrosion promoters like water or oxygen getting under the coating and accelerating corrosion.

in the substrate.



Kett's LZ-373 US aerospace analyzer works on both ferrous and non-ferrous substrates.

SIMPLIFYING COATING THICKNESS MEASUREMENT

Although traditional laboratory and online based coating thickness measurement techniques are useful in the right settings, they have lacked the simplicity and flexibility required for frequent spot checks. Often, this involves sampling, sample preparation, and taking the sample to the lab for evaluation, which requires the participation of staff adequately trained for the process.

Other conventional coating tests, such as scratch testing, have been destructive or invasive and damaged the sample. This meant that a product could not be returned to the production line, or that a coated surface had to be recoated or repaired in the field at additional expense. Also, since only a small portion of the component may be tested, results may not be representative of the entire situation. Consequently, various portable coating thickness measurement devices have been developed. However, these have not always provided the necessary accuracy or been sufficiently easy to use.

Another drawback is that in certain environments with multiple substrates, the devices typically either had difficulty determining the substrate or utilizing the correct test for the application. So, multiple measurement devices had to be used, which complicated testing and added cost.

Finally, typical coating measurement methods were usually unable to accurately measure curved or complex surfaces. This left pipe, piping, and convoluted component designs largely unable to be easily spot checked for coating compliance.

In response, aerospace industry innovators have developed a number of advanced designs for handheld coating thickness test devices. For units used on the production line and in the field, these significantly improve accuracy, versatility, and ease of use.

One example is a portable coating thickness gauge which combines two of the most widely used measurement methods, magnetic inductance and eddy current, in a dual mode device that can measure the coating thickness of almost any non-magnetic coating on both ferrous (magnetic) and non-ferrous (non-magnetic) substrates. Since the unit is able to automatically determine the substrate and use the appropriate measurement circuit, this enables instant, non-


destructive testing on painting, plating, anodizing, and organic coatings with accuracy up to 0.1 μm . Such testing takes less than a second to display the measurement.


Because the key to providing accurate, repeatable measurements is the operator's ability to reliably make consistent contact between the instrument and the test surface, the unit also utilizes a spring-loaded probe to generate a consistent contact pressure with the measured surface. This integrated probe also includes built in edge guides to enable easy measurement of even curved and edged surfaces. To ensure device stability during measurement, the foot of the probe is also designed to provide a firm platform when placed onto the test piece.

A number of other design considerations in handheld coating thickness gauges can also simplify measurement and improve versatility. In order to improve accuracy and durability on the aerospace factory floor or in the field, it is best for the unit to have no moving parts, other than the probe. Similarly, the unit should be impervious to vibration, with measurement independent of its orientation.

To save time during the testing process, it's recommended to utilize a unit with a large screen that enables the quick reading of results. Those results should be able to be stored in the gauge and transferred to a computer and/or printer for documentation and averaging purposes. An instrument that stores many test measurements is best so operators can perform numerous tests before downloading the results.

Easier, more accurate aerospace coating and plating measurement with handheld units will help to improve quality checks wherever needed. So, defects can be immediately detected and corrective action undertaken to minimize scrap and faulty components or aircraft.

*This article was written by John Bogart, Managing Director, Kett US (Villa Park, CA).
For more information, visit [here](#) .*



Aerospace Manufacturing and Machining Magazine

This article first appeared in the June, 2020 issue of *Aerospace Manufacturing and Machining Magazine*.

Read more articles from the archives [here](#).

SUBSCRIBE 