$S \cdot O \cdot L \cdot U \cdot T \cdot I \cdot O \cdot N \cdot S^{\circ}$

MODERN

WWW.MCSMAG.COM

P

NDUST

ON PROJECTS

COVID-19 IMPACT

R

THE EQUIPMENT & BUSINESS SOLUTION FOR CONCRETE & GENERAL CONTRACTORS

-

-PURPOSE

MENT

CONTRACTOR

VERTICAL EXPANSION BUILDING UP

KNOW THE PROCESS

RESOLUT

DISPUTE

JUNE 2020

point-and-measure Moisture Meters

handheld analyzers deliver lab-quality moisture readings in seconds



crucial part of managing any large-scale construction project is staging the work as efficiently as possible so the crew and any subcontractors remain busy while maintaining building quality. However, when moisture or water is part of the equation, decisions about proceeding to next steps, waiting for materials to dry or cure, or even ensuring the ideal ratio of water in adhesives and slurry mixes can be even more critical. The risk can be quality issues, costly rework, mold, shrinking/expansion/warping of materials, and other construction matters.

MOISTURE CONCERNS

On most construction sites, there can be uncertainty about moisture levels for a variety of reasons. Building materials can be unintentionally exposed to rain, snow, or humidity during framing; unexpected events such as plumbing leaks can occur; drying and curing times of adhesives, mastics, concrete, or other materials can be difficult to ascertain; and even the moisture content in raw materials, such as powders or lumber, may be unclear.

Although the construction industry has access to moisture meters, to some extent, these tools typically require calibration, sampling, and time. In addition, they are not very flexible in measuring a variety of materials in various forms (wet, powder, solid) and certainly are not portable enough to be used on jobsites.

PORTABLE MOISTURE METER

Fortunately, a new category of portable, handheld, instant moisture measurement devices are now available for construction workers that can be used on a wide range of materials with no special training.

These "point-and-measure" units can be used at the jobsite wherever moisture is a problem or a specified moisture content needs to be known to proceed with work, whether that involves sand,



aggregate, concrete mixes, adhesives, wood frame construction, drywall, or other materials. This new tool is helping expedite project completion and improve building quality for as little as \$20 a day when the equipment is leased.

SIMPLIFYING MEASUREMENT

Although traditional laboratory and online based moisture measurement techniques are useful in the right settings, they have lacked the simplicity and flexibility required for frequent spot checks on a jobsite.

One common test is Loss on Drying, which measures the total material weight change after drying. However, such tests typically require a sample to be prepared and brought to a lab. The test takes a minimum of 15 minutes up to several hours to perform.

Because such traditional moisture tests are too slow, laborious, and alter or destroy the sample, they are not practical for construction sites. Instead, what is needed is a fast, easy "point-and-measure" method to determine moisture content.

So, industry innovators have developed a simplified approach with testing equipment that utilizes Near-Infrared (NIR) light, a highly accurate, non-contact secondary measurement method that can deliver immediate, laboratory quality moisture readings.

"NIR moisture meters allow very accurate instant measurement of solids, slurries, and liquids without contact or sample preparation in portable handheld models," says John Bogart, managing director of Kett US, a manufacturer of a full range of moisture and organic composition analyzers.

MEASURING MOISTURE CONTENT

Bogart says that once the meter has been calibrated against lab or production standards, the calibrations are stored in the device so no calibration is required in the field. The calibrations are stored in different "channels" in the unit, each dedicated to a specific type of building material. The user simply selects the proper channel and the measurement is instantly displayed.

According to Bogart, NIR moisture meters follow the principle that water absorbs certain wavelengths of light. The meter reflects light off the sample, measures how much light has been absorbed, and the result is automatically converted into a moisture content reading.

"You can use the NIR meters on anything where measuring surface moisture is important," says Bogart.

At a construction site, for example, an NIR meter could be used to instantly check the moisture level of bulk "dry" goods such as sand or aggregate on receipt from suppliers. It could also be used to spot check the moisture content of materials mixed with water.

Bogart says the same approach could help to speed the installation of flooring or tile while ensuring quality control.

"A NIR meter can determine if mastic or adhesive has the correct moisture content to properly bond floor, wall, and ceiling tiles so creep, shrinkage, buckling, or grout problems do not become an issue," he says.

When measuring moisture content inside a variety of building materials such as lumber, concrete, mortar, gypsum board, or OSB is necessary, portable electronic, contact gauge testers are also available.

"Handheld contact gauges can measure the moisture inside many kinds of samples at superficial or deeper levels just seconds after contact with the material," says Bogart.

As an example, with lumber for framing, once the user sets the thickness of measurement and specific gravity of the wood and touches the sample with the instrument, the moisture content for all kinds of wood is instantly displayed. To avoid dimensional change problems, the U.S. Department of Agriculture's Wood Handbook recommends average moisture content of 15 percent or less, with maximum readings of 19 percent or less.

CLOSING THOUGHT

While the industry has not routinely spot-checked moisture levels in materials during construction, doing so consistently will significantly speed job completion and improve building quality by removing any doubt as to drying time or moisture content.

for more information

For more about Kett US and its full range of moisture and organic composition analyzers, visit www.kett.com.

Knowledge Is Your Competitive Edge



As a business owner you know fierce competition on a daily basis. Keeping your company's edge is vital to your business success.

ATP strives to be the best at providing workers with the most current information needed to attain the skills and knowledge to succeed.

Check us out!



800.323.3471 • atplearning.com

TRACKS N TEETH

- RUBBER TRACKS
- REPAIR PARTS
- CAT ENGINE PARTS

CALL NOW FOR A FREE QUOTE!

TRACKSNTEETH.COM

(206) 486-4995

- UNDERCARRIAGE
- FINAL DRIVES
- •MUCH MORE!