

[HOME](#)
|
[FACTORY](#)
|
[SENSORS](#)

Smart Sensors for Moisture Measurement

With quality assurance procedures continuing to move away from inspection and toward a real-time, continuous approach relying on process feedback, Kett has leveraged the growing computing power of sensors to provide a better means of measuring moisture.

Author — [David Miller](#)

Jan 12th, 2021



Quality control is perhaps at the heart of good manufacturing with tarnished or inferior goods resulting in sunk costs at best and disgruntled or unsatisfied customers at worst. In the past, much quality control has occurred after the fact with finished goods being inspected in batches to ensure they meet certain standards. However, this approach has several drawbacks. For instance, should a quality defect result from a faulty production process, it may affect an entire batch of finished goods, meaning that they may all need to be disposed of so that the line can be run again.

Luckily, changes in technology are **trending away from inspection after that fact and toward real-time, continuous quality assurance methodologies**, which allow such prospects to be avoided. In addition to the use of **artificial intelligence (AI) and machine learning algorithms** to **size up production output in real time** or even predict issues in advance, **more sophisticated sensors also play a large role by providing the necessary input data.**

Among the many metrics that manufacturers may track—particularly in process industries such as food and beverage, chemical, pharmaceuticals, or pulp and paper—is moisture. Limiting excess moisture is vital, not only to meet certain regulatory standards, but to ensure proper chemical reactions and drying for pharmaceuticals, as well as maximizing shelf life and deterring mold in the food and beverage space.

“Whether manufacturers are mixing, blending, homogenizing, or drying, non-contact, smart inline technology enables the rapid, automatic measuring of moisture in 100% of product or inputs, along with the ability to instantly fine-tune the process. This can optimize quality as well as minimize waste and corrective re-processing,” said John



AutomationWorld
LEADERSHIP IN
AUTOMATION 2021

INSTRUMENTATION

- Acromag
- Endress+Hauser
- MAVERICK Technologies, LLC, A Rockwell Company
- MTS Sensors
- ProComSol

SENSORS, DISCRETE

- Digi-Key Electronics
- MTS Sensors
- Newark, An Avnet Company
- Telemecanique Sensors

SENSORS, PROCESS

- MTS Sensors
- Telemecanique Sensors

[View All Companies >](#)

Bogart, managing director of **Kett**, a manufacturer of moisture and organic composition analyzers.

Kett provides smart sensors capable of calculating moisture quickly using on-board computing power, a capability made possible by the ever-expanding amount of capacity being packed into ever-smaller microprocessors. Kett's sensors are also capable of transmitting data in real-time to smart phones, PCs, and other devices even if they are not connected to a plant's network architecture. In addition, these sensors can automatically send alerts to notify operators when certain parameters and limit conditions have been surpassed. Moreover, storing this data can allow for the tracking of historical performance trends, cyclical rhythms, and periodic failures, helping plant personnel to move from a reactive to a proactive approach.



Continuous moisture monitoring powered by smart technology allows for the tracking of historical performance trends.

Perhaps just as importantly, by foregoing conventional laboratory testing methods that often require bulky equipment replete with cords and cabling of various sorts, valuable floor space can be saved. This is a growing concern across industry that's driving numerous trends ranging from **modular conveyance options** to the **use of edge controllers to eliminate the need for control cabinets**.

“With typical testing, by the time results come back from the lab, any off-spec product can already be processed, packaged, and shipped. If manufacturers are not measuring in real-time, inevitably there will be some variation in inputs, process, and quality,” Bogart said. “Fitting inline testing equipment into space-

restricted production lines can be difficult when wires and cables must be run to a variety of peripheral instruments. In such cases, the cost of labor, installation, and system integration can be as much as the device itself.”

Kett's approach works by using near-infrared (NIR) light as a non-contact measure, which enables them to collect and transmit several times per second, resulting in real-time metrics that save time, labor, and costs.

According to Bogart, NIR moisture meters can provide highly accurate measurements of solids, liquids, and slurries without any need for contact or sample penetration, meaning there is no risk of contamination. In addition, once the meter has been calibrated to typical laboratory production standards, the calibration data can be stored inside the device so that there is no need for excessive programming or configuration. Monitoring capabilities can also be integrated with the accompanying Kett Tracker data collection and analysis software to improve error detection, defect analysis, and quality results.

“Ultimately, smart moisture measurement technology translates into superior process control, quality, and production without the inherent drawbacks of slower, labor-

intensive lab or batch testing,” Bogart said.

COMPANIES IN THIS ARTICLE

Kett



Sensors

Smart Sensors for Moisture Measurement

With quality assurance procedures continuing to move away from inspection and toward a real-time, continuous approach relying on process feedback, Kett has leveraged the growing compu... better means of measuring moisture.

David Miller

Jan 12th, 2021



Sensors

Vision and Control on One CPU

Though combining multiple control functions on one controller is not particularly new, the high compute and bandwidth requirements of vision have typically required it to exist on a separate controll... are changing that reality.

David Greenfield

Nov 18th, 2020



Sensors

How Artificial Intelligence Works in Quality Control

The use of artificial intelligence has been growing across the industrial automation space for the several years now. But do you really understand what it does to affect outcomes?

David Greenfield

Oct 13th, 2020



Supplier News

Posital Announces Position Sensors with Modbus RTU Interface

Sep 1st, 2020



Home

Compressed Air Measurement Helps Reduce Energy Use

Installing Festo's E2M energy efficiency modules helped medical device and pharmaceutical manufacturers tackle their environmental footprint, not only saving money but using the data to provide predictive maintenance as well.

Aaron Hand

Aug 18th, 2020



Sensors

Smart Sensor for Variable Speed Equipment

Petasense releases its Vibration Mote Model 3 smart sensor that detects speed, vibration, and temperature.

David Greenfield

Jul 21st, 2020



Home

Vision Inspection Maximizes Label Accuracy

For one North American food manufacturer, Omron's SKU verification system dramatically lowered production costs and increased overall profitability.

Matt Reynolds

Jul 15th, 2020



Sensors

Technology Matters: Wearable Sensors, Vision Systems, Industrial Networking

In this episode we look at wearable sensor technologies for social distancing, using vision systems to inspect liquids and solids, and the rise of publish/subscribe



Home

Temperature Sensors Help Maintain Correct Fluid Viscosity

Improve process quality and machine performance

Balluff, Inc.

Jun 15th, 2020