

IN THIS ISSUE:



**Up front** —  
A new high-tech Innovation Centre



**Analysis** —  
The key to spraying smooth epoxy coatings.



**Spotlight** —  
Protecting the Steel Curtain roller coaster.



INTERNATIONAL

## The Leading Marine & Protective Coatings Magazine

July — September 2019

[pce-international.com](http://pce-international.com)



### PROTECTING AN ICON

The Steel Curtain roller coaster, which recently opened in Pittsburgh's historic Kennywood Park, features a Steelers Yellow colour that was custom-formulated for the project.



# How thick is your coating?

From the job shop to the robotic assembly floor, it is vital that the product be made well and correctly coated for protection, aesthetics, and performance.

**I**ndustries such as the automotive and aerospace industries for example, and those utilising plating, anodising, powder or other coatings, need accurate coating thickness measurement. This is particularly important when the coatings play a critical role in preventing the corrosion or wear of metal substrates.

Properly applied coatings, with thickness measured in mils (.001 inch) or microns (.001 mm), are also essential for paint/coatings contractors and companies that coat a wide range of building and functional surfaces, including pipe. Accurate application and coating thickness measurement are crucial to avoid coating breaches leading to corrosion of the underlying substrate. This can help to prevent leaks and other safety issues in a wide range of industries.

However, until recently conducting frequent laboratory-quality coating thickness tests throughout the manufacturing process or in the field has been difficult. Traditionally, this required meticulous sampling and preparation, as well as taking the sample to the lab for evaluation. Although portable coating thickness gauges are not new, Kett US claims that most

fail to provide the accuracy, speed, or simplicity required for anyone to conduct quick checks as needed on the production line or in the field.

Fortunately, the company says that handheld devices are now available that allow personnel to easily and quickly perform lab-quality coating thickness measurements. Some options offer instant coating thickness measurement of almost any non-magnetic coating on both ferrous (magnetic) and non-ferrous (non-magnetic) substrates. This is possible using only one hand, even on curved and complex surfaces.

By simplifying the process, industrial facilities and paint/coatings contractors and companies can increase the quality of their products and services from start to finish, while optimising cost.

## MANY BENEFITS

Coating thickness directly affects product quality, whether for automotive paint, electroplating, anodising, or a wide range of other coating applications. For example, checking the paint coating consistency on a vehicle not only provides a product with a superior finish, but can also offer essential data about the consistency of the paint when it is



“

Incorrect paint consistency can affect drying times, or eventual flaking of the paint film — too little paint coating and you are left with cosmetic issues in opacity, and protective issues like corrosion, wear and exposure.

”

wet. “Incorrect paint consistency can affect drying times, or eventual flaking of the paint film,” says John Bogart, Managing Director of Kett US, a manufacturer of a full range of coating thickness testers. “Too little paint coating and you are left with cosmetic issues in opacity, and protective issues like corrosion, wear and exposure. Checking coating thickness can also tell if auto body work has been done on a used car, which can help the customer or dealer make a good decision on pricing.”

When specificity and adhesion matter in anodising and electroplating, a coating thickness gauge should be able to read the thickness of the coating to the most minute measurement. This can play a major factor in preventing corrosion, while optimising the process by eliminating any excess use of the expensive plating product.

Another way a coating thickness gauge can make a significant impact is in testing anti-corrosion pipe coatings to find weak spots, where the coating is too thin and a breach of the coating could make the substrate susceptible to corrosion, according to Bogart. “Knowing about these trouble spots can prevent a disaster well before it occurs,” he explains. “This might involve petrochemical pipes in a facility, water pipes in a home or office, or even the piping and tubing in an engine.

“A nondestructive gauge is a perfect way to ensure that the pipe’s protective coating has not been applied too thinly, or become so over time,” he adds. “Excessively thin coatings are more likely to be chipped or breached, which can lead to corrosion promoters like water or oxygen getting under the coating and accelerating corrosion in the substrate.”



### SIMPLIFYING MEASUREMENT

Although traditional laboratory and online based coating thickness measurement techniques are useful in the right settings, they have lacked the simplicity and flexibility required for frequent spot checks claims Kett. Often, this involves sampling, sample preparation, and taking the sample to the lab for evaluation, which requires the participation of staff adequately trained for the process.

Other conventional coating tests, such as scratch testing, have been destructive or invasive and damaged the sample. This meant that a product could not be returned to the production line, or that a coated surface had to be recoated or repaired in the field at additional expense. Also, since only a small portion of the component or facility may be tested, results may not be representative of the entire situation.

Consequently, various portable coating thickness measurement devices have been developed. However, these have not always provided the necessary accuracy or been sufficiently easy to use says Kett.

Another drawback is that in certain environments with multiple substrates, the devices typically either had difficulty determining the substrate or utilising the correct test for the application. So, multiple measurement devices had to be used, which complicated testing and added cost.

Finally, typical coating measurement methods were usually unable to accurately measure curved or complex surfaces claims the company. This left pipe as well as convoluted component designs largely unable to be easily spot checked for coating compliance.

### INDUSTRY RESPONSE

In response, industry innovators have developed a number of advanced designs for handheld coating thickness test devices. For units used



on the production line and in the field, these significantly improve accuracy, versatility, and ease of use.

One example, the LZ990 portable coating thickness gauge by Kett combines two of the most widely used measurement methods, magnetic inductance and eddy current, in a dual mode device that can measure the coating thickness of almost any non-magnetic coating on both ferrous (magnetic) and non-ferrous (non-magnetic) substrates.

Since the unit is able to automatically determine the substrate and use the appropriate measurement circuit, this enables instant, non-destructive testing on painting, plating, anodising, and organic coatings with accuracy up to 0.1  $\mu\text{m}$ . Such testing takes less than a second to display the result.

As the key to providing accurate, repeatable measurements is the operator's ability to reliably make consistent contact between the instrument and the test surface, the unit also utilises a spring-loaded probe to generate a consistent contact pressure with the measured surface. This integrated probe also includes built in edge guides to enable easy measurement of even curved and edged surfaces. To ensure device stability during measurement, the foot of the probe is also designed to provide a firm platform when placed onto the test piece.

#### OTHER DESIGN CONSIDERATIONS

According to Bogart, a number of other design considerations in handheld coating thickness gauges can also simplify measurement and improve versatility.

In order to improve accuracy and durability on the factory floor or in the field, it is best for the unit to have no moving parts, other than the probe. Similarly, the unit should be impervious to vibration, with measurement independent of its orientation.

To save time during the testing process, he recommends utilising a unit with a large screen that enables the quick reading of results. Those results should be able to be stored in the gauge



and transferred to a computer and/or printer for documentation and averaging purposes. An instrument that stores many test measurements is

best so operators can perform numerous tests before downloading the results.

"Easier, more accurate coating and plating measurement with handheld units will help to improve quality checks wherever needed," concludes Bogart. "So, defects can be immediately detected and corrective action undertaken to minimise scrap and faulty end-products."

## PosiTector<sup>®</sup> SST Soluble Salt Tester

Measures the concentration of soluble salts on metal surfaces using the Bresle method

- Displays test duration, sample temperature, conductivity ( $\mu\text{S}/\text{cm}$ ) and surface density
- Easy 1-2-3 gage interface guides users through the Bresle method
- Includes PosiSoft suite of software for viewing and reporting data



Innovative PosiPatch<sup>™</sup>

- No adhesive residue
- No sharps, no needles!

For use with all Bresle patch types including the innovative PosiPatch



**DeFelsko<sup>®</sup>**  
The Measure of Quality

1-800-448-3835  
[www.defelsko.com](http://www.defelsko.com)

 Made in U.S.A.

DeFelsko Corporation • Ogdensburg, New York USA  
Tel: +1-315-393-4450 • Email: [techsale@defelsko.com](mailto:techsale@defelsko.com)